



**KEGEL
MECHANICS
KLUB**

**Buffer Brush
Goes Up/Down
Continuously**

Start

**Tighten Set Screw on
Flat Spot of Brush Lift
Motor**

**Brush Lift Cam Tight
on Motor Shaft**

No

Yes

**Adjust Micro Switch
Roller to Cam with
.015 Gap**

**Micro Switch Adjusted
Properly**

No

Yes

**Replace Broken Wire or
Reattach Loose Wire**

Yes

**Click to Email KMK
Expert**

**Micro Switches
are Activating 0ch4 &
0ch5**

Yes

No

**GN/WH Wire
to 0ch4 or VT/YE to
0ch5 is Broken or
Loose**

No

**Replace Switch
P/N: 153-1203**